

Installation Instructions

Thank you for ordering your Entergy Mississippi Operation Bill Assist Energy Efficiency Kit. The instructions below are provided to assist you with the installation of your new faucet aerators, power strip and weatherstripping.

Faucet Aerators

To install your new efficient-flow faucet aerators, watch the video linked [here](#) or follow the step-by-step instructions below.

You'll need: washers, old toothbrush, rag and plumber's tape

1. Remove the old aerator from the faucet by turning it counterclockwise.
2. Using an old toothbrush and rag, clean and dry the threaded area of the faucet thoroughly.
3. Insert the washers provided into the aerator to prevent leaks.

For internal-threaded faucets:
place provided thinner washer on top of the thicker washer on the top of the aerator.

For external-threaded faucets:
discard the thicker washer and place the provided thinner washer on the top of the aerator.

4. Attach the new aerator to the faucet by turning clockwise and hand-tighten until snug. **DO NOT OVER-TIGHTEN.**
5. If you notice any leaks after turning the water on, remove the aerator, wrap the threads of the aerator with the plumber's tape provided and reattach.

Enjoy your new efficient faucet aerator.

Power Strip

To install your new advanced power strip, watch the video linked [here](#) or follow the step-by-step instructions below.

1. Plug your new advanced power strip into an electric wall outlet and flip the black switch on the side of the power strip to "ON".
2. Plug your TV or PC into the black master outlet on the power strip.
3. Devices that should be powered all the time (i.e., router, cable box or DVR) should be plugged into a black "ALWAYS ON" outlet on the power strip.

These outlets receive power even if the master device is turned off.

4. Plug any accessory devices (i.e., speakers, printer or game system) should be plugged into the teal "SWITCHED" outlets on the power strip.

When your master device is ON, these devices can power on.

When your master device is turned OFF, these devices are automatically switched OFF and stop using power. You don't need to do anything.

Enjoy the peace of mind and energy savings your new power strip provides.

Weatherstripping

To install your new v-seal weatherstripping, watch the video linked [here](#) or follow the step-by-step instructions below.

You'll need: pliers, cloth, soap and water, fine grit sandpaper, scissors and measuring tape

1. Remove any old weatherstripping, including old adhesive or tape. Stubborn adhesive or tape can be removed carefully with pliers.
2. Remove any dirt or debris from the door jamb using your cloth and soap and water. For any stubborn buildup, you can use fine grit sandpaper.
3. Measure the perimeter of the door jamb to determine how much weatherstripping you'll need for the top and each side of the door.
4. Cut three pieces of weatherstripping to match the measurements in Step 3.
5. Starting at the bottom of one side of the door and working your way up and around to the other side, peel away the adhesive backing from the weatherstripping and firmly press it into place around the perimeter of the door jamb.
6. If desired, use heavy duty staples or small tacking nails to reinforce weatherstripping.

You've now eliminated unwanted drafts and can enjoy the comfort your weatherstripping provides.